




ENVIRONMENTAL TECHNOLOGY

Installation & Operating Manual

MIXMASTER IV, V, VI, VII



INSTALLATION INSTRUCTIONS

Pre-Installation Checks

- (i) Check that shaft outside diameter is within tolerance of $\pm 0.002''$ ($\pm 0.05\text{mm}$) of seal size, particularly in the areas of the seal drive clamp and the sealing 'O' ring(s).
- ii) Check that the gearbox bearings (and motor if applicable) conform to the manufacturers recommended values for axial and radial clearance.

Investigate and remedy any discrepancies before fitting the seal. For seals with no integral steady bearing, the maximum allowable radial shaft movement at the mounting flange is 1.0mm TOTAL (t.i.r.). This should be checked using a dial gauge or other suitable instrument. There must be a minimum clearance of 0.5mm between stationary and rotating parts after allowing for any bearing clearance.

Maximum axial movement must not exceed $\pm 1\text{mm}$ (i.e. 1 mm either way from the installed position), for example if thrust reversal can cause the shaft to move upwards from the at-rest position.

- iii) Clean and dimensionally check the mating faces of the mounting flange. Using a dial gauge mounted on the shaft, check that the seal mounting surface is at right angles to the shaft axis to within the values shown in table 1, and that the shaft is central to the mounting flange to within 0.5mm. Where compressible or adjustable gaskets are used, the final seal alignment must be checked against the table. Where the seal has an integral bearing used as the lower shaft bearing, these checks can be performed by assembling the equipment without the seal, then allowing the shaft to 'hang' from the upper bearing.

Squareness of equipment flange to shaft

For seals to DIN 28138 see DIN 28161 (Measurement C)

For seals not to DIN 28138

Seal nominal size (mm)	TIR Per 25mm (1.000") of r (mm)	(inches)
40	0.065	0.0025
50	0.048	0.002
60	0.039	0.0015
80	0.049	0.002
100	0.03	0.0012
125	0.028	0.001
140	0.024	0.00095
160	0.022	0.00087

Table 1

r = Distance to dial gauge measurement from centre line of shaft.

INSTALLATION INSTRUCTIONS


- (iv) The seal shall be assembled to the shaft and vessel flange in accordance with the manufacturers specific instructions. The following points are of general importance.
- Check that there are no sharp edges over which the seal 'O' rings must pass.
 - Lubricate the shaft with the grease provided, except under the drive clamp.
 - Ensure no excessive forces are exerted whilst positioning the seal.
 - Assemble all equipment parts in final running position, prior to securing the mechanical seal.
 - Fix the seal into position applying uniform load to diametrically opposite bolts / studs - (see fig. 3).
 - Uniformly tighten the screws associated with the seal drive clamp (see fig. 3).
 - Disengage the setting clips - (see figs. 1 & 2).
 - If possible, rotate the shaft by hand by one complete revolution to check for any resistance to motion.
 - Connect the quench and drain to ports A & B.
 - Ensure barrier fluid is present before start up, and the seal is primed, (free from trapped air).
 - The incidental leakage port "C" should be connected with suitable pipe work, to safely collect and dispose of any barrier/buffer fluid leakage.
- v) Clean surrounding area of pot, then carefully remove plug on pot top-up branch.
- vi) Using a suitable funnel or filler pump, add fluid to bring the level back to 13mm (0.512") below the top of the sight glass.
- vii) Replace top-up plug and tighten.
- viii) Pressurise seal support system, start pump (if fitted), and observe for leaks and correct operation.

NOTE:

- 1) Ensure that the seal is firmly bolted to the vessel flange, with the shaft already in position before removing the setting clips.
- 2) Prior to full commissioning, run the equipment, with the seal full of sealant for a period of approximately one hour and check for excessive temperature, noise and vibration at the seal position. It is advised that the vessel has a sufficient level of liquid during running (check the manufactures recommended instructions).


Disengaging Setting Clips

Fig. 1



- Ensure the Setting Clips are disengaged prior to equipment start-up.
- Ensure the Setting Clips are engaged before removing the seal and transporting.

Fig. 2



Disassembly

- Stop operation.
- Release the pressure in the vessel.
- Release the sealant system pressure.
- Drain the sealant.
- Stop the cooling water circulation (where applicable).
- Disconnect the sealant pipes and where applicable, the cooling water pipes from the seal unit.
- Engage the clips.
- Disconnect the clamp device.
- The further disassembly of the vessel and drive has to be carried out in accordance with the instructions of the drive manufacturer.

Seal Maintenance

- Monitor the sealant pressure.
- Monitor the coolant water circulation (where applicable).

Seal Lubrication

- Self-aligning roller bearings are grease filled. Bearings must be lubricated through grease nipple 'G' with the specified grease at the usual intervals for this kind of bearing. For correct grease type refer to product information.

Flange & Clamp Screw Tightening

Tighten the screws in the following sequence:

a,e → c,g → b,f → d,h

Repeat the sequence until secure.

Refer to GA Drawing for Correct Torque Figure.




Fig. 3

INSTALLATION INSTRUCTIONS

Thermosyphon Systems

These are widely used on applications with low heat removal requirements, and are extremely reliable if correctly installed. The following guidelines should be observed:

- The pot should be sited at a MIN 1 meter MAX 2 meter above the seal. No more than 1 meter from the side of the seal. See Fig. 4
- Seal return pipe must slope gradually from the seal to the pot. NO SAGS!
- Minimise number of fittings. No right-angled fittings.
- Minimum bend radius 100mm. NO KINKS!




Fig. 4

NOTE:

Some loss of barrier fluid in normal operation is to be expected, typically up to 1 litre per week. The rate of loss is affected by service conditions, particularly radial shaft motion. A sudden loss of fluid, or an increasing rate of loss, indicates a problem with the process conditions, the equipment, the seal or its support system.

Dry-running seals

Check barrier gas pressure and flow daily.

NOTE: Some fluctuation in flow rates is normal; Nitrogen usage is affected by service conditions. A sudden increase in flow rate, or a gradually increasing flow rate, indicates a problem with the process conditions, the equipment, the seal or its support system.

THIS DOCUMENT IS DESIGNED TO PROVIDE DIMENSIONAL INFORMATION AND AN INDICATION OF AVAILABILITY. FOR FURTHER INFORMATION AND SAFE OPERATING LIMITS CONTACT OUR TECHNICAL SPECIALISTS AT THE LOCATIONS BELOW.



USE DOUBLE MECHANICAL SEALS WITH HAZARDOUS PRODUCTS. ALWAYS TAKE SAFETY PRECAUTIONS:

- GUARD YOUR EQUIPMENT
- WEAR PROTECTIVE CLOTHING



UK Sales & Technical advice:

AESSEAL plc
Mill Close
Templeborough
Rotherham
S60 1BZ
United Kingdom

Telephone: +44 (0) 1709 369966
Fax: +44 (0) 1709 720788
E-mail: seals@aes seal.com
Internet: <http://www.aes seal.com>

Distributed by:

Our Purpose: 'To give our customers such exceptional service that they need never consider alternative sources of supply.'

USA Sales & Technical advice:

AESSEAL Inc.
355 Dunavant Drive
Rockford,
TN, 37853
USA

Telephone: +1 865 531 0192
Fax: +1 865 531 0571
E-mail: usa@aes seal.com

ALL SIZES ARE SUBJECT TO MANUFACTURING TOLERANCES. WE RESERVE THE RIGHT TO MODIFY SPECIFICATIONS AT ANY TIME.